


Bedienungsanleitung für die HPVELOTECHNIK Blinkanlage WingBling

Für Besitzer/-in und Nutzer/-in eines Trikes mit Blinkanlage

Die HPVELOTECHNIK Blinkanlage ist eine Einrichtung zum Anzeigen einer geplanten Fahrtrichtungsänderung im Straßenverkehr.

Am Lenker befindet sich ein Blinkschalter mit 2 grünen Kontroll-LEDs. An der Vorder- und Rückseite des Trikes ist jeweils eine rechte und linke Blinkleuchte montiert.



Bilder 1-3 von oben nach unten: Blinkschalter, Blinker an der Trike-Vorderseite, Blinker an der Trike-Rückseite. Die Montage an Ihrem Trike kann variieren.

Bedienung:

Schalten Sie das Elektro-Antriebssystem ein. Schalten Sie die Lichtanlage ein, wenn sie nicht automatisch zusammen mit dem Elektro-Antrieb eingeschaltet wird.

Drücken Sie den Schalter mit dem nach rechts zeigenden Pfeil: Sowohl vorne als auch hinten blinkt die Anlage auf der rechten Seite.

Beide Kontrollleuchten am Schalter blinken. Bringen Sie den Blinkerschalter nach der Richtungsänderung in die Mittelstellung, um das Blinken zu beenden. Dies geschieht nicht automatisch.

Der linke Blinker wird entsprechend über den Schalter mit dem nach links weisenden Pfeil betätigt.


Die Kontrollleuchten am Schalter zeigen an, dass die Anlage blinkt, nicht auf welcher Seite die Leuchten blinken. Ein Ausfall einer Kontrollleuchte zeigt einen Defekt an. Suchen Sie in diesem Fall einen Fachhändler auf. Bei Fahrten im Straßenverkehr mit defekter Blinkanlage geben Sie Handzeichen um eine Änderung der Fahrtrichtung anzuzeigen.

Die Blinkerleuchten sind an leicht flexiblen Armen befestigt. Diese können Sie, wenn nötig, vorsichtig ausrichten.

Gefahr

Die im Rahmeninneren verlegten Kabel sind mit dem Elektroantrieb verbunden und stehen unter Spannung. Bei Beschädigungen der Kabelverbindung kann es zu einem Kurzschluss und in Folge zum Ausfall des Elektroantriebsystems kommen.

Sollte ein Defekt auftreten, wenden Sie sich an einen Fachhändler.



Entsorgung:

Die Blinkeranlage handelt es sich um ein Elektrogerät, das nicht über den Hausmüll entsorgt werden darf. Beachten Sie die geltenden Abfallordnung an Ihrem Wohnort.

Stand Juli 2019

Instruction Manual for the HP VELOTECHNIK Indicator System WingBling

For owner and user of a trike with indicator system

The HP VELOTECHNIK indicator system is a device for showing a planned change of direction in road traffic.

There is an indicator switch with 2 green LEDs on the handlebar. On both the front and rear side of the trike there is a right and left indicator light.



Fig. 1-3 from top to bottom:
Indicator switch, indicators on the trike's front side, indicators on the trike's rear side. The mounting situation on your trike can vary.

Operation:

Switch on the electric drive system.

Switch on the lighting system if it is not automatically started together with the electric drive.

Press the switch button with the arrow pointing to the right: the indicator lights on the right side flash at the front and at the rear. Both LEDs on the

switch flash.

Move the push button of the switch to the middle position to stop the flashing. This does not happen automatically.

The left indicator is activated accordingly by the switch button with the arrow pointing to the left. The indicator lights on the switch indicate that the system is working correctly, not on which side the lights are flashing. A failure of a LEDs indicates a defect. In this case, contact a specialist dealer. When driving in road traffic with a defective indicator system, give hand signals to indicate a change of direction.

The indicator lights are attached to slightly flexible arms. If necessary, you can adjust them carefully.

Danger

The cables inside the frame are connected to the electric drive system and are live. Damage to the cable connection may result in a short circuit and consequently in failure of the electric drive system. If a defect should occur, contact a specialist dealer.



Disposal:

The indicator system is an electrical device that must not be disposed of with household waste. Observe the waste regulations in force at your place of residence.

Version July 2019